

Document Camera Controls



Document Camera Instructions

- Press the power button.
- Switch LCD to proper input for document camera. (See remote control directions on “Getting Started” page.)
- Place Document on the Document Camera Base.
- Select lamp setting if needed.
- Adjust white balance if needed.
- Be sure to **turn off** Document Camera and LCD when you are finished.











-  **- Power Button**
To turn on press and hold until light turns **Green**.
To turn off press and hold until light turns **Red**.
-  **- Automatic Focus Button**
Press this button to focus your documents.
-  **- Text and Photo Button**
Use this button to display your documents better.
If you are displaying photos, use the “photo” setting, if you are displaying text, use the “text” setting.
-  **- Menu Button**
The menu button will take you to two main **manual** adjustments: Brightness and Focus. These adjustments will display on the screen and you will use the left and right arrow keys on the **arrow pad** to adjust them.
-  **- AWB (Automatic White Balance Button)**
This button will automatically adjust the white color of the display on the screen.
Place anything white under the lens, and press this button once to set white balance.
-  **- Lamp Setting Button**
This button will switch between three lamps settings, “lamp off”, “base lamp” and “side lamps.”
- If you are using the side lamps, be sure to push the “LAMP RELEASE” latch forward.
(If you are using transparencies use the “base lamp” option. If you are using non transparencies, you can use either the “lamp off” or “side lamps” for additional light.)
-  **- Zoom in Button**
This button allows you to zoom in from a document to see the whole document.
-  **- Zoom out Button**
This button allows you to zoom out to a specific portion of the document.


Diagram 2





Elliot TT-12 Document Camera



Key


 - **Power Button**
To Turn on press and hold until light turns **blue** To turn off press and hold until Light turns **Red**.


 - **Power Indicator**
No light = No power
Red light = power, in standby mode
Blue Light = light on


 - **Automatic Focus Button**
Press this button to focus your documents.


 - **Lamp Setting Button**
This button will turn the light arm on or off.


 &  - **Brightness Adjustments**
Use these controls to turn up the brightness for dark documents or turn down the brightness for light documents.



 - **Menu button**
This menu button will take you to two main manual adjustments: Brightness and Focus. These adjustments will display on the screen and you will use the left and right arrow keys on the **arrow pad** to adjust them.





 - **Source Button**
This button is only used if you are looping your PC/Laptop through your Document Camera. This button will switch between the internal (doc cam) and external (PC/Laptop.)


 - **Capture Button**
Use this button to capture still pictures of your documents that are stored in the document camera until deleted.

 - **Play Button**
Use this button to play back stored photos.

 &  - **Zoom Control**
Use these controls to turn up the brightness for dark documents or turn down the brightness for light documents.



Remote Control



Getting Started

- Press the power button.
- Switch LCD to proper input for document camera. (See remote control directions on "getting started" page.)
- Place Document under the Document Camera Lens on the PLATEN.
- Turn Light off or on if needed.
- Adjust the zoom and focus if needed.
- Be sure to turn off Document Camera and LCD when you are finished.

New Dukane 335 Document Camera

For Help, Contact MSC at MSC@usna.edu or call 410-293-4028

New Dukane 335 Document Camera



Getting Started

- Press the power button.
- Switch LCD to proper input for document camera. (see remote control directions on "getting started" page)
- Place Document under the Document Camera Lens.
- Select lamp setting if needed.
- Adjust white balance and focus if needed.
- Be sure to turn off Document camera and LCD when you are finished.



Remote Control

- Power Button**
To turn on press and hold until light turns green.
To turn off press and hold until light turns red.
- Power Indicator Light**
No light = no power.
Red light = power, in standby mode.
Blue Light = on.
- Menu Button**
The menu button will take you to two main manual adjustments: Brightness and Focus. These adjustments will display on the screen and you will use the left and right arrow keys on the arrow pad to adjust them. The arrow pad is labeled with the red arrows.
- Automatic Focus Button**
Press this button to focus your documents.
- AWB (Automatic White Balance Button)**
This button will automatically adjust the white color of the display on the screen. Place anything white under the lens, and press this button to set white balance.
- Auto Adjust Button**
This button will perform both the White Balance and Focus functions at the same time.

- Text and Photo Button**
Use this button to display your documents better. If you are displaying photos, use the "photo" setting, if you are displaying text, use the "text" setting.
- Image Flip Button**
Use this button to flip your image.
- Lamp Setting Button**
This button will turn your light arm on or off.
- Brightness Adjustments**
Use these controls to turn up the brightness for dark documents or turn down the brightness for light documents.
- Source Button**
This button is only used if you are looping your PC/Laptop through your Document Camera. This button will switch between the internal (doc cam) and external (PC/Laptop.)
- Capture Button**
Use this button to capture still pictures of your documents (stored in the document camera until deleted.)
- Play Button**
Use this button to play back stored photos.
- Delete Button**
Use this button to delete stored photos in Document Camera.