

GALLEY STOVE INSTRUCTIONS

LIGHTING THE STOVE:

1. RUN THE ENGINE BLOWER FOR AT LEAST 30 SECS.
2. TURN ALL BURNERS AND OVEN OFF (RIGHTY-TIGHTY).
3. ENSURE THE TANK IS TIGHTLY CONNECTED TO THE HOSE.
4. OPEN THE VALVE ON THE PROPANE TANK.
5. FLIP THE "LPG STOVE" CIRCUIT BREAKER ON. [DC PANEL]
6. FLIP THE SOLENOID SWITCH ON. [JUST ABOVE THE OUTBOARD FORWARD CORNER OF REEFER]
7. APPLY A LIT MATCH TO THE BURNER.
8. TURN ON THE BURNER.

SECURING THE STOVE:

1. LEAVE ONE BURNER BURNING; TURN ALL OTHER BURNERS AND THE OVEN OFF.
2. TURN THE VALVE ON THE PROPANE TANK OFF.
3. WATCH THE FLAME ON THE OPEN BURNER GO OUT.
4. TURN THE BURNER OFF.
5. FLIP THE SOLENOID SWITCH OFF.
6. FLIP THE LPG STOVE CIRCUIT BREAKER OFF.

LIGHTING THE OVEN:

1. LIGHT A BURNER USING THE PROCEDURE ABOVE TO BLEED AIR FROM THE LINES.
2. MAKE SURE YOU HAVE ACCESS TO PLACE A FLAME NEXT TO THE OVEN ELEMENT.
3. TURN THE CONTROL VALVE COUNTER CLOCKWISE ABOUT 90 DEGREES.
4. HOLD A FLAME NEXT TO THE OVEN ELEMENT AND DEPRESS THE PILOT BUTTON.
5. CONTINUE TO HOLD THE BUTTON FOR 15-20 SECONDS AFTER THE OVEN ELEMENT HAS A FLAME TO HEAT THE THERMOCOUPLE.
6. CONTROL THE OVEN TEMPERATURE WITH THE CONTROL KNOB.
7. SECURE THE BURNER ON TOP.

SECURING THE OVEN:

1. LEAVE OVEN GOING AND ENSURE ALL BURNERS OFF.
2. TURN THE VALVE ON THE PROPANE TANK OFF.
3. WATCH THE FLAME ON THE OVEN ELEMENT GO OUT.
4. CLOSE THE OVEN CONTROL KNOB.
5. FLIP THE SOLENOID SWITCH OFF.
6. FLIP THE LPG STOVE CIRCUIT BREAKER OFF.